



All parapets **MUST** be capped with metal flashing by the main contractor in accordance with NZBC E2/AS 1.

All carpentry works and materials shall be provided by the main contractor.

For roofing underlay & plywood installations, refer to Installation Guide.

Specified cladding by the architect on building wrap on timber frame.



All cladding clearances shall be accordance with manufacturers' specifications.

150mm upstand Stepped Butynol or colour steel flashing, installed by ASRNZ.
(Refer to Sheet 06 / 1.61 ~ 1.65)

Pabco Asphalt Shingle over waterproof underlay on 15mm plywood on timber frame.

ROOF FRAME

File Name: 2.60 - Parapet to Roof Junction Detail.dwg	Scale: 1:2 @ A4	Drawn By: I.M	Date: 28th January 2013
--	--------------------	------------------	----------------------------

Drawing Name: Parapet to Roof Junction Detail	Sheet: 12
--	--------------



Ph: 09 636 7051 | Fax: 09 636 7053 | Free Ph: 0800 261 116 | e-mail: info@asphaltshingle.co.nz
www.asphaltshingle.co.nz | PO Box 24 676, Royal Oak, Auckland, New Zealand

- * All constructions are to comply with New Zealand Building Standards and Territorial Authority Regulations.
- * The contractor shall verify all dimensions and levels on site before commencing work.
- * These drawings are not to be used for construction without Territorial Authority Consent.
- * Do not attempt to reproduce these drawings in any unlawful manner without the consent of Asphalt Shingle Roofing NZ.
- * These drawings may be utilised in order to create working drawings for submission to a Territorial Authority or certifier for consent purposes.